

## Download SmartCONTROL app

Télécharger l'application SmartCONTROL  
Laden Sie die App herunter SmartCONTROL  
Descarga la aplicación SmartCONTROL  
Scaricare l'applicazione SmartCONTROL




## Add remote control in App

Ajouter la télécommande dans l'app  
Fernbedienung in app hinzufügen  
Añadir el mando en la aplicación  
Aggiungere il telecomando nell' app



1




2



Select «My Controllers»  
Sélectionner «Mes Contrôleurs»  
Wählen Sie «Meine Controller»  
Seleccionar «Mis Controladores»  
Selezionare «i miei Telecomandi»

3

Put remote control in «smartphone» mode  
Mette la télécommande en mode «smartphone»  
Fernbedienung in «Smartphone» -Modus setzen  
Poner el mando en modo «smartphone»  
Impostare il telecomando in modalità «smartphone»




## Add a light bulb in app

Ajouter une ampoule dans l'app  
Fügen Sie eine Glühbirne in der App hinzu  
Añadir una bombilla en aplicación  
Aggiungere una lampadina nell' App




1



2

Follow the wizard  
Suivre l'assistant  
Folgen Sie dem Assistenten  
Seguir el menú  
Seguire la procedura guidata



## Compatibility

Compatibilité  
Kompatibilität  
Compatibilidad  
Compatibilità




Eglo LED Connect  
AwoX SmartLIGHT Mesh

For more information, read the user guide

Pour plus d'information, lire le mode d'emploi  
Weitere Informationen finden Sie in der Bedienungsanleitung  
Para más información, leer la guía del usuario  
Per ulteriori informazioni, leggere il manuale d'uso

<http://www.awox.com/user-guides>




Mesh Remote Control & Light Bulb  
Télécommande Mesh & Bombilla  
Mesh Fernbedienung & Glühbirne  
Mando de control Mesh & Bombilla  
Telecomando Mesh & Lampadina



AwoX SmartControl




1





3

### 3 seconds long press

Appui long de 3 secondes  
Für 3 Sekunden drücken  
Presión larga de 3 segundos  
Premere a lungo 3 secondi




2




No blink. Redo step  
Pas de clignotement. Refaire  
Kein Blinzeln. Wiederholen  
Sin parpadeo. Volver al  
Ripeti il passaggio

Blink  
Clignotement  
Blinkend  
Luz intermitente  
Lampeggiante




### Select a Color

Sélectionner une couleur  
Wählen Sie eine Farbe  
Selezionare un color  
Selezionare un colore



### Record as a favorite

Enregistrer comme favori  
Als Favorit festlegen  
Guardar como favorito  
Registra come preferito




3 seconds long press  
Appui long de 3 secondes  
Für 3 Sekunden drücken  
Presión larga de 3 segundos  
Premere a lungo 3 secondi

### Select an Intermediate Color


Sélectionner une couleur intermédiaire  
Wählen Sie eine Übergangsfarbe  
Selezionare un color intermedio  
Selezionare un colore intermedio



A



B



Multiple click  
Appui successif  
Mehrmals klicken  
Presiones sucesivas  
Stampa multipla

